

## Product information according to Commission regulation (EU) No 66/2014

| Attribute Name                    | Position     | Symbol                   | Value                   | Unit |
|-----------------------------------|--------------|--------------------------|-------------------------|------|
| Model Denomination                |              |                          | HGX64200SB<br>949641064 |      |
| Type of hob                       |              |                          | Built-In Hob            |      |
| Number of gas burners             |              |                          | 4;Mariane               |      |
| Energy efficiency per gas burner  | Left Front - | EE <sub>gas burner</sub> | 58.6                    | %    |
|                                   | Left Rear -  | EE <sub>gas burner</sub> | 62.8                    | %    |
|                                   | Right Rear - | EE <sub>gas burner</sub> | 60.8                    | %    |
| Energy efficiency for the gas hob |              | EE <sub>gas hob</sub>    | 60.7                    | %    |

### EN 30-2-1: Domestic cooking appliances burning gas - Part 2-1 : Rational use of energy - General"

Suggestions for a correct use in order to reduce the environmental impact:

- Before use, make sure that the burners and pan supports are assembled correctly.
- Use cookware with diameters applicable to the size of burners.
- Center the pot on the burner.
- When you heat up water, use only the amount you need.
- If it is possible, always put the lids on the cookware.
- When the liquid starts to boil, turn down the flame to barely simmer the liquid.
- If it is possible, use a pressure cooker. Refer to its user manual."